

## Buoyancy Factors

FLUID WEIGHT LB./GAL.	BUOYANCY FACTOR	FLUID WEIGHT LB./GAL.	BUOYANCY FACTOR
6.0	0.9083	13.0	0.8013
6.2	0.9053	13.2	0.7983
6.4	0.9022	13.4	0.7952
6.6	0.8991	13.6	0.7922
6.8	0.8961	13.8	0.7891
7.0	0.8930	14.0	0.7861
7.2	0.8900	14.2	0.7830
7.4	0.8869	14.4	0.7800
7.6	0.8839	14.6	0.7769
7.8	0.8808	14.8	0.7738
8.0	0.8778	15.0	0.7708
8.2	0.8747	15.2	0.7677
8.3	0.8727	15.4	0.7647
8.4	0.8716	15.6	0.7616
8.6	0.8686	15.8	0.7586
8.8	0.8655	16.0	0.7555
9.0	0.8625	16.2	0.7524
9.2	0.8594	16.4	0.7494
9.4	0.8564	16.6	0.7463
9.6	0.8533	16.8	0.7433
9.8	0.8502	17.0	0.7402
10.0	0.8472	17.2	0.7372
10.2	0.8441	17.4	0.7341
10.4	0.8411	17.6	0.7311
10.6	0.8380	17.8	0.7280
10.8	0.8350	18.0	0.7249
11.0	0.8319	18.2	0.7219
11.2	0.8289	18.4	0.7188
11.4	0.8258	18.6	0.7158
11.6	0.8227	18.8	0.7127
11.8	0.8197	19.0	0.7097
12.0	0.8166	19.2	0.7066
12.2	0.8136	19.4	0.7035
12.4	0.8105	19.6	0.7005
12.6	0.8075	19.8	0.6974
12.8	0.8044	20.0	0.6944

Buoyancy Factor compensates for loss of weight due to immersion in fluid. Data applies only when tubing is completely filled with fluid.

### CONTACT

**Tenaris Coiled Tubes**  
 8615 E. Sam Houston Pkwy N.  
 77044 Houston Texas USA  
[coiledtubesales@tenaris.com](mailto:coiledtubesales@tenaris.com)  
 (1) 281 458 2883 tel  
 (1) 281 458 2886 fax